



#K3015 AUTOMATIC TIRE INFLATOR

1. SET THE PRESSURE
2. PUSH START
3. TIRE INFLATES
4. UNIT STOPS AT SET PRESSURE

- **UNIQUE DESIGN** allows the tire pressure to be preset on the readout
- **PUSHING START** automatically fills the tire to the set pressure
- **SAVES TIME** and allows tires to be filled accurately

SPECIFICATIONS:

- Inflation range to 175 psi
- Requires (7) AA batteries, not included
- 1 Preset pressure input
- Accuracy +/- 1 psi
- Air Compressor Required

